


INSTRUCTION OF AIRGATE



1 After unpacking the airgate put it on the ground and open the airgate outfull.



2 Next secure the clamps to the airgate.



3 Connect the plug socket in order to start the processing of inflated. Remember not to cover the extractor fan.



4 Plug with extension can be secured by inserting into the airgate.




5 Close the zip by base of the airgate.



6 Wait until the airgate is inflated.



7 After the airgate is inflated secure the other end of the rope into the ground with a hammer and pegs.



8 Follow the previous two steps and secure all ropes to the gate and ground. By using the cord and ropes try to regulate the vertical of airgate.



9 The last stage is secure the base of airgate by using the pegs hammer into the ground through the pegs-gap.