

## INSTRUCTION OF MOUNTING THE INFLATABLE TENT



1

After unpacking lay the tent on the ground.



2

Close the zip on the leg and connect the plug to the mains.



3

Air starts to fill the tent. Remember not to cover the extractor fan.



4

Wait until the tent will stand on 4 legs.



5

Unpack 4 sidewalls and zip them to the tent.



6

Now secure hammer tent to the ground (by using tent - pegs hammer).



7

First hammer 4 legs by the tent-pegs into the ground.



8

Next hammer sidewalls to the ground.



9

Tent is ready to use.